



PERMA TECH, INC.

363 HAMBURG STREET
BUFFALO, NEW YORK 14204

PHONE: (716) 854-0707

FAX: (716) 854-0774

1-800-362-7325

WWW.PERMATECHINC.COM

PERMA COLLAPSIBLE SHELTER

INSTALLATION INSTRUCTIONS

NOTE:

CHECK SHIPPING CONTAINERS BEFORE RELEASING CARRIER.
NOTIFY CARRIER IMMEDIATELY UPON DISCOVERING ANY CONCEALED DAMAGE.

WARNING

DO NOT INSTALL THIS PRODUCT UNLESS YOU READ AND UNDERSTAND THE WARNINGS AND INSTALLATION INSTRUCTIONS CONTAINED IN THIS MANUAL.
FAILURE TO DO SO COULD RESULT IN SERIOUS INJURY OR DEATH.

INSTALLATION INSTRUCTIONS

COLLAPSIBLE SHELTER

SERIES 5000

NOTE: Check shipping containers before releasing carrier. Notify carrier immediately upon discovering any concealed damage.

1. Measure the length of the side frames (2 x 6).
2. Measure the length of the header frame (2 x 6 with optional taper). Find and mark the centerline.
3. Measure the door lintel and mark the centerline.
4. Install side frames (2 x 6), making sure they are plumb. (Keep unit retracted for ease of handling.)
5. Match the centerlines of the door lintel and header 2 x 6 and install the header 2 x 6 above the side frames.
6. The header cross tubing (with 2 ½" legs) should now be inserted into the tops of side frame tubing.
7. Remove aluminum angles from side frame for replacement when curtains are installed.
8. **SPRING ADJUSTMENT:** Open shelter to maximum extension. Unhook the spring from the chain attached to the slide pipe. Move the spring hook up the amount of chain links you desire to apply more outward pressure on the unit.
9. Top and side projection curtains are three separate units. Unpack the side curtains and attach to side frame tubing using $\frac{5}{16}$ " x 2 ½" hex bolts with nuts and washers on the back. The grommet holes in the curtain line up with the holes drilled in the aluminum angle. Hook the side curtain shock cords to the center of header tubing.
10. Nail the hemmed edge of side curtains to the wooden side frames going from top to bottom. Use just enough nails to support the curtain (approx. 5 or 6).
11. Unpack the header curtain and drape over frame tubing. Beginning at the center and working out, nail the hemmed edge of the curtain to the wooden head frame (using just enough nails to hold the curtain in place), and then nail the molding strip to the frame (use one every 12" to 18").
12. Pull the header curtain over the frame tubing and attach the aluminum angle by bolting to the frame. Connect the Velcro strips on both sides.
13. Nail the side frame molding strips to the frames (use one every 12" to 18"). Be sure to go over the header Velcro attachment.
14. In order to attach the header wind restraint, strap on each side of header, remove one of the bolts near the top of the side aluminum angles. Then, slip the wind strap underneath the angle and re-bolt through the wind strap and the side curtain. (See detailed drawing, figure 1, on back of booklet.)
15. Attach the 2 inch "NO STEP" cushions to the back of the curtains with Velcro. Nail the attached shock cord to the corresponding wooden frame (2 x 6).
16. Caulk around entire unit.

